



SHERPA JK CUTLERY KEEPER

FOR THE OUTBACK ADVENTURES TRAILGATER JK

Installation Instructions

1. Remove the top left screw holding the Trailgater to the tailgate.
2. Insert that screw through the top left grommet in the Cutlery/Tool Panel and put the screw back in the original hole in the Trailgater, leaving the screw slightly loose at this point.
3. Continue clockwise around the Trailgater, removing/reinserting each screw in turn.
4. When all six screws are installed in the Cutlery/Tool Panel, tighten all screws snugly.



Please note: Because the Cutlery/Tool Keeper is made from natural cotton and leather, it will stretch slightly over time. This is normal and because of this the initial fit of the panel is designed to be very tight. It will be tightest between the two screws on the bottom; there are four screws across the top which will control stretching over time, but because the TrailGater only has two screws on the bottom, the panel is designed to be tight between those two screws. Doing the screws in clockwise order, starting at the top left, you'll have to pull the bottom right corner a bit to stretch it to put the screw in, and stretch it a bit more for the bottom left screw.

