



Sherpa Door Pockets for the '11-'18 JK Wrangler

Installation Instructions

The Sherpa Door Pockets can be secured to the door panel in two ways – with self-adhesive Velcro, or with screws. If you plan to carry heavier loads on the Molle panel/in the door pockets or you don't want to apply sticky Velcro to the door panel, we recommend using screws. If you'd rather not drill 3 small holes in the door panel, you can first use the Velcro method and if your loads increase to the point where the Velcro isn't sufficient, you can always install the screws later. Whichever method is used to secure the pockets to the door panel, installation is basically the same.

Tools required:

- Phillips screwdriver
- T-25 Torx driver
- Trim pry tool

1. Remove the two screws securing the bottom of the door panel to the door.

2. Pry off the trim in the center of the door panel. This can be done with a plastic trim tool, or with a small screwdriver. The plastic can be protected from scratching by a layer of masking tape on the screwdriver as shown. Pry gently to allow finger access to the underside of the trim and pull the trim off the door. Once the trim is removed, remove the lower of the two screws under the trim.



3. Starting at the bottom where you removed the screws from the panel, pull the panel gently away from the door. The goal is to pull the lower half of the panel out far enough to release the pins that secure the panel to the door.



4. Slip the door pocket around the bottom of the door panel, making sure the door pins go through the holes in the back of the door pocket. You will need to reach behind the panel to guide the fabric over the pins so the pins go into the holes in the fabric. Once all the pins are through the holes, pull the panel up tight and push the door panel back in place, being careful that the pins go back in the appropriate holes.



5a. If you plan to use the self-stick Velcro to secure the pockets, put the self-stick Velcro hook patches on the Velcro loop patches on the back of the pockets, pull the adhesive off the Velcro one patch at a time, pull the door pocket up tightly and press the self-stick Velcro onto the door panel.



5a. If you plan to use screws to secure the pockets, pull the door pocket up tightly and using a 1/16" drill bit make a hole through one grommet at a time. Insert a screw through that grommet and tighten it into the hole you just drilled. Put screws in the other two grommets the same way.

6. Replace the screws that you removed from behind the trim panel and replace the trim panel. Replace the screws you removed from the bottom corner of the door panel.



Sherpa Door Pockets

Care Instructions

Your new Sherpa Door Pocket is made from heavy cotton duck canvas fabric and is designed to give years of service on the road and trail. Canvas is very easy to clean and handle - a soft and dry bristled brush can be used to remove any loose dust or dirt.

If the canvas needs further cleaning, mix clean water and a small amount of mild detergent and use a damp towel or bristled brush dipped in the solution and scrub or rub the dirty areas gently. Lightly spray the canvas area with water to remove the soap residue and dry with a towel.

To keep the Door Pockets looking new longer, we recommend treating the fabric with Scotchgard Auto Fabric & Carpet Protector. Scotchgard provides excellent resistance to water, oil and stains and it doesn't change the look and feel of the fabric, so the fabric stays soft and colors stay true. Scotchgard comes in an easy-to-use spray bottle.

Note: Do not Dry-Clean, bleach or put in the dryer as these may potentially discolor the canvas.

