




SHERPA JL CUTLERY KEEPER

FOR THE GOOSE GEAR TAILGATE TABLE



SHERPA JL CUTLERY KEEPER


FOR THE GOOSE GEAR TAILGATE TABLE



Installation Instructions

1. The Cutlery Keeper is attached with the same screws that secure the table to the tailgate (indicated by arrows above). To install the Cutlery Keeper, remove the screws one at a time, put the Cutlery Keeper in place and replace the screws.

2. The corners are secured to the Goose Gear panel with self-stick Velcro. Ensure that the aluminum surface is clean, peel the backing from each self-stick circle of Velcro, stretch the corners out a bit and stick the Velcro to the panel.



Installation Instructions

1. The Cutlery Keeper is attached with the same screws that secure the table to the tailgate (indicated by arrows above). To install the Cutlery Keeper, remove the screws one at a time, put the Cutlery Keeper in place and replace the screws.

2. The corners are secured to the Goose Gear panel with self-stick Velcro. Ensure that the aluminum surface is clean, peel the backing from each self-stick circle of Velcro, stretch the corners out a bit and stick the Velcro to the panel.

